

Aquid Patina

USE LIQUID PATINA INSTEAD OF WAX FOR A SIMPLE, DURABLE FINISH FOR INDOORS & OUTSIDE!



*Allow your piece to dry for at least 24 hours before you begin to apply liquid patina to ensure the paint is set.

*You will need: 2-3 dry, lint-free cloths; with dark patina, have a damp cloth, and an extra dry cloth at hand.

To we:

- 1.) Pour a small amount of liquid patina onto a rag, a sponge, or directly onto your dry surface.
- 2.) Spread the liquid evenly with a dry/damp cloth or sponge, covering the area completely.

Debia tipa:

*LIQUID PATINA DRIES QUICKLY- AVOID WORKING IN DIRECT SUNLIGHT, SO YOU HAVE MORE TIME TO SPREAD THE FINISH BEFORE IT DRIES.

*WORK IN SMALL SECTIONS TO AVOID A PATCHY FINISH.

*WHEN USING A DARK PATINA, BE READY WITH A WET RAG TO REMOVE EXCESS PRODUCT BEFORE IT DRIES, AND A DRY CLOTH TO ABSORB WETNESS.

*LAY DOWN SOME CLEAR LIQUID PATINA BEFORE A DARK PATINA TO DILUTE SOME OF THE STAIN.

*FINISH PIECE WITH A LAYER OF CLEAR PATINA TO MAXIMIZE PROTECTION